

Application Note

AN1007-00, 2014-01-20 Getting Device Information





Notice

Registered Trademark



ARETE mobile is launched by PHYCHIPS Inc. for mobile device and currently registered worldwide with its ARETE mobile trade mark legally protected by law.

© 2014 PHYCHIPS Inc. All rights reserved.


This document is produced by PHYCHIPS Inc. and protected by Copyright Laws. Please note that there may be possible mistake or omission of information in this document.




Revision History

Version	Date	Changes
00	2014-01-20	Initial released

APP is converting binary bit stream to audio wave to transmit data to ARETE POP. This process is using audio player API in OS. ARETE POP is generating audio wave to transmit data to smart phone and APP is using audio recorder API in OS to capture audio wave. RCP API constructs and deconstructs RCP Packet. Additionally, converting bit-to-wave and vice versa. To learn more about RCP, please refer to A100_SM1001 SDK manual.



To get device information, you should call **getReaderInfo** method. This method is generating RCP packet whose command code is 0x03. Then RCP is converted into wave format.





Arguments for **getReaderInfo** is shown below.

Model (0x00)

S/N (0x01)

STATUS (0xB0)


INFO (0xB1)

For example, to get unique device ID, set 0x01 for argument.

RcpApi.getReaderInfo(0x01) for Android

[self.rcp getReaderInfo:0x01] for iOS

When ARETE POP received command, it would return RCP response as shown below. If RCP is arrived at the smart phone, the smart phone calls call-back method, **onReaderInfoReceived** (Android) or **readerInfoReceived** (iOS). Call-back method is implemented as delegate (at iOS) and interface (Android).



Preamble	Msg Type	Code	PL (MSB)	PL (LSB)	Argument		
0xBB	0x01	0x03	0x00	0x08	0x50 (P)	0x48 (H)	0x59 (Y)
		Argument	End Mark	CRC-16			
0x43 (C)	0x48 (H)	0x49 (I)	0x50 (P)	0x53 (S)	0x7E	0xNNNN	



Argument of RCP response is the same as call-back method.

```
public void onReaderInfoReceived(int[] data)
{
   String SN = RcpLib.int2str(data);
}

- (void)readerInfoReceived:(NSData *)data
{
   NSString SN = [[NSString alloc] initWithData:data encoding:NSUTF8StringEncoding];
}
for iOS
}
```



ARETE mobile Customer Service

Phone: + 82 42 864 2402 Fax: + 82 42 864 2403

Email: sales@phychips.com

Address

PHYCHIPS Inc.

#104 Migun Technoworld 2, 187 Techno 2-ro, Yuseong-gu, Daejeon, Korea 305-500

Working Day and time

Monday to Friday 09:00~18:00(Korean Time, GMT Time + 9 hours)

Local Customer Service

Please contact where you buy.