



Application Note
AN1014-00, 2014-10-10
Error Code



Notice

Registered Trademark



ARETE mobile is launched by PHYCHIPS Inc. for mobile device and currently registered worldwide with its ARETE mobile trade mark legally protected by law.

© 2014 PHYCHIPS Inc. All rights reserved.

This document is produced by PHYCHIPS Inc. and protected by Copyright Laws.
Please note that there may be possible mistake or omission of information in this document.

Revision History

Version	Date	Changes
00	2014-10-10	Initially released

ARETE POP firmware had been updated to report the extended error code. The new RCP packet is assigned 3 bytes for error code while the legacy packet has 1 byte of error code. The first byte of error code is the same as the legacy error code for backward compatibility. Next 2 bytes have more information.

Preamble	Msg Type	Code	PL (MSB)	PL (LSB)	Error Code	End Mark	CRC-16
0xBB	0x01	0xFF	0x00	0x01	[0]	0x7E	0xNNNN



Preamble	Msg Type	Code	PL (MSB)	PL (LSB)	Error Code	Error Code	Error Code
0xBB	0x01	0xFF	0x00	0x02	[0]	[1]	[2]
End Mark	CRC-16						
0x7E	0xNNNN						

Android and iPhone Api also report 3 bytes error code.

iOS	@optional - (void) failureReceived:(NSData *)errCode
Android	void onFailureReceived(final int[] errCode)
Description	You can override this method to perform additional tasks associated with RCP error.
Parameters	errCode[0]: RCP error code. - 0x09: Failure to read the tag memory - 0x0B: 'startReadTags' in Operation - 0x0D: Not in mode 'Read Type C Tag ID Multiple' - 0x0E: Invalid parameter - 0x10: Failure to write data - 0x12: Failure to kill a tag - 0x13: Failure to lock a tag - 0x15: Failure to read a tag - 0x18: Not supported command - 0xFF: CRC Error errCode[1]: Command code errCode[2]: More information
Return Value	None

■ The third byte gives more information shown below.

- ✓ 0x00 – 0x0F : EPC Gen2 V2.0 Error Message
 - 0x00 : Other error
 - 0x01 : Not supported
 - 0x02 : Insufficient privileges
 - 0x03 : Memory overrun
 - 0x04 : Memory locked
 - 0x05 : Crypto suite error
 - 0x06 : Command not encapsulated
 - 0x07 : ResponseBuffer overflow
 - 0x08 : Security timeout
 - 0x0B : Insufficient power
 - 0x0F : Non-specific error
- ✓ 0x10 – 0x7F : Vendor Specific Error Code
 - 0x11 : Sensor scheduling configuration (EM4325)
 - 0x12 : Tag busy (EM4325)
 - 0x13 : Measurement type not supported (EM4325)
- ✓ 0x80 – 0x8F : [PHYCHIPS] Protocol Error
 - 0x80 : FAIL_NO_TAG_DETECTED
 - 0x81 : FAIL_HANDLE_ACQ
 - 0x82 : FAIL_PASSWORD
- ✓ 0x90 – 0x9F : [PHYCHIPS] Modem Error
 - 0x90 : FAIL_CRC_ERROR
 - 0x91 : FAIL_RX_TIMEOUT
- ✓ 0xA0 – 0xEF : Reserved
- ✓ 0xF0 – 0xFF : [PHYCHIPS] Common Error
 - 0xF0 : FAIL_NOT_SUPRT_CMD
 - 0xF1 : FAIL_UNDEF_CMD
 - 0xF2 : FAIL_INVALID_PARM
 - 0xF3 : FAIL_TOOHIGH_PARM
 - 0xF4 : FAIL_TOLOW_PARM
 - 0xF5 : FAIL_READ_AUTO_OP
 - 0xF6 : FAIL_NO_AUTO_MODE
 - 0xF7 : FAIL_RDR_RESET
 - 0xF8 : FAIL_GET_LAST_RSP
 - 0xF9 : FAIL_CTRL_TEST
 - 0xFF : FAIL_CMD

ARETE mobile Customer Service

Phone: + 82 42 864 2402

Fax: + 82 42 864 2403

Email: sales@phychips.com

Address

PHYCHIPS Inc.

#104 Migun Technoworld 2, 187 Techno 2-ro, Yuseong-gu, Daejeon, Korea 305-500

Working Day and time

Monday to Friday

09:00~18:00(Korean Time, GMT Time + 9 hours)

Local Customer Service

Please contact where you buy.